

➤ Topic #1: Peer-to-Peer Network Configuration using Windows Server

Note: Windows Server 2019 and Windows 10 have the same For Windows Server 2019, things need to accomplish: environment. Apply the same settings.

- Task 1. To start Changing the IP Address
- > Open Control Panel
- > Go to "Network and Internet"
- > Look for "Network Sharing Center"
- > Click "Change adapter Settings"
- > Right click (on the Ethernet or Local Area Network)
- >Select "Properties" >Select Internet Protocol version 4(TCP/IPv4)
- >Properties Select "use the following IP Address." IP Address: 192.168.9.2 Subnet Mask:
- 255.255.255.0 Click OK and Close the Properties window.
- > Done Configuring the IP Address

- Task 2. To Turn off Password Sharing>>>
- > Open "Control Panel"
- > Go to "Network and Internet"
- > Look for "Network Sharing Center"
- > Click on "Change Advanced Sharing Settings"
- > Expand the "All Networks Profile"
- Locate and Turn-off Password protected Sharing"
- >Save Changes

- Task 3. To Change Computer Name of Client
- >Click "Start"
- > Open "Control Panel"
- > System and Security
- > Locate and open "System"

Configuring Server PC (Windows 10)

- Task 1. To start Changing the IP Address>>
- > (Select the box and it will be filled automatically)
- > Open Control Panel
- > Go to "Network and Internet"
- > Look for "Network Sharing Center"
- > Click "Change adapter Settings"
- >Right click (on the Ethernet or Local Area Network)
- Select "Properties" > Select Internet Protocol version 4(TCP/IPv4)
- > Properties Select "use the following IP Address." IP Address: 192.168.9.2 Subnet Mask: 255.255.255.0 Click OK and Close the Properties window.
- > Done Configuring the IP Address

- Task 2. To Turn off Password Sharing>>>
- > Open "Control Panel"
- > Go to "Network and Internet"
- > Look for "Network Sharing Center"
- > Click on "Change Advanced Sharing Settings"
- > Expand the "All Networks Profile"
- > Locate and Turn-off Password protected Sharing"
- Save Changes

- Task 3. To Change Computer Name of Client PC>>>>
- > Click "Start"
- > Open "Control Panel"
- System and Security
- > Locate and open "System"
- >Click "Change Settings"
- System Properties, Click "Change"
- > Type the "Computer name: "SERVERPC"
- > Click "Ok" to save the changes.
- restart Computer or the computer will restart automatically.
- Note: that the changes will not take effect until the PC restar

- Task 4. Create a Shared Folder>>>
- >Right Click on the desktop.
- Select "New" then select "Folder"
- Type the name of your folder then press enter (Example: Server Folder)
- > Right Click on Folder then Select "Properties"
- Select "Sharing" Tab > Click "Share"
- >On the drop-down menu >Select "Everyone" and Click "Add"
- > Make sure that the permission level is "Read/Write"
- >Click "Share" and When pop-up network discovery and file sharing appear, choose Yes, turn on network discovery..... >Click "Done" > Go to "Advanced Sharing"
- > Tick/check the box "Share this folder"

- > Click on "permissions"
- > Tick/check the box "Full Control" under "Allow" permission
- > Click Apply then "Ok"; > Click Apply then "Ok", and
- > close the Folder properties (we are done creating a shared folder)
- >Click "Advance System Settings"
- System Properties, Click "Change"
- > Type the Computer name: "CLIENTPC"
- > Click "Ok" to save the changes.
- > restart Computer or the computer will restart automatically.

Note: that the changes will not take effect until the PC restart

Now, we are finished Configuring both Computers.

Check the network connectivity using ping command prompt.

Task-2 Open CMD Type: "ipconfig" to get the IP address of both computers.

Type: "ping 192.168.9.1" for windows server 2019

Type: "ping 192.168.9.2" for Windows 1