COC2


SET-UP COMPUTER NETWORK

Computer Network

- Consist of two or more computers connected together through communication media to share information & resources.
 - Communication Media
 - **✓** UTP Cable
 - **√** RJ45
 - ✓ Network Hub
 - ✓ Patch Panel
 - ✓ Router

—UTP Cable

Unshielded Twisted Pair




— RJ45

Registered Jack #45

Modular connectors were originally used in the Registration Interface system, mandated by the Federal Communications Commission(FCC) in 1976 in which they became known as registered jacks. The registered jack specifications define the wiring patterns of the jacks, not the physical dimensions or geometry of the connectors of either gender. Instead, these latter aspects are covered by ISO standard 8877, first used in ISDN systems. TIA/EIA-568 is a standard for data circuits wired on modular connectors.







—Network Hub/Switch

A network switch (also called switching hub, bridging hub, officially MAC bridge) is a computer networking device that connects devices together on a computer network, by using packet switching to receive, process and forward data to the destination device. Unlike less advanced network hubs, a network switch forwards data only to one or multiple devices that need to receive it, rather than broadcasting the same data out of each of its ports.




—Patch Panel (Power over Ethernet)

A patch panel, patch bay, patch field or jack field is a device or unit featuring a number of jacks, usually of the same or similar type, for the use of connecting and routing circuits for monitoring, interconnecting, and testing circuits in a convenient, flexible manner. aka Bridge

Typical LAN Premise Wiring

of a network.



—Router

Used to DHCP Server

- ➤ ADSL

 Transmit IP Address to

 Server (Computer)
- Access Point
 To extend the range of wireless connection










Diagram of Network on (TESDA-CSS)



NETWORKING TOOLS NEEDED




UTP Cable (Color Coding) for RJ45



UTP Cable (Color Coding) for RJ45


Color Standard EIA/TIA T568B

Ethernet Patch Cable




Color Standard EIA/TIA T568B


Ethernet Crossover Cable




UTP Cable (Color Coding) for RJ45




UTP Cable (Color Coding) for Patch Panel







UTP Cable (Color Coding) for Patch (Modular Box)













Note: Reset the device into Factory Setting by pressing the "Factory reset" button in 5 to 10sec.

- the indicator is when the lights(LED) are flash all together or "Turn On" the device is ready or reset.

Check the connection:

- ✓ On the desktop of your Computer
 - Network tray next open Network Sharing
- ✓ On the Start Menu Control Panel Network & Internet
 - Network and Sharing Center Change adapter setting Local Area Connection(LAC)
 Note: Check if your device (Router/ AP) connected
 - ❖ Go to LAC for IP ADDRESS Checking given by the ROUTER
 - ❖ Go to Start search bar type RUN (to enter DOS or Command Prompt) inside the DOS
 - type IPCONFIG or ipconfig






STEP 1: Log into the router from your computer

- You will need to have a working network card or port with a computer attached in order to connect to the ADSL router. These instructions assume the default router setup. This guide assumes that you have set up all the physical connections as per the welcome note, found inside the router's box or at the back of device.
- Open a browser (Internet Explorer, Mozilla Firefox, Google Chrome etc.) and type the brand of the router e.g. http://tplinkmodem or type http://192.168.1.1 in the address bar




• The browser should ask you for username and password, use username: admin and password: admin (these are the default for Linksys routers, refer to your manual if they don't work)



STEP 2: Configure Local Wireless Settings

- The wireless access point is deactivated by default. To activate it securely follow the steps outlined below.
- Click on Interface Setup.
- Click on Wireless.
- Select Activated.
- From the Channel dropdown select United States.
- **Choose a name** for your wireless access point and enter it next to *SSID*.
- From the Authentification
 Type dropdown select WPA-PSK.
- **Choose a password** that is not easily guessable of at least 8 characters and enter it next to *Pre-Shared Key*.
- Click SAVE to save the new wireless settings.




STEP 3: Configure Local Area Network(LAN) Settings

- The LAN is deactivated by default. To activate it securely follow the steps outlined below.
- Click on Interface Setup.
- Click on LAN.
- Choose and change for your LAN IP ADDRESS and enter it next to IP ADDRESS.


NOTE: You must change only the third(3rd) digit of your IP (192.168. .1)

 Click SAVE to save the new LAN settings.



STEP 4: Configure Local Area Network(LAN) Settings

- The LAN is deactivated by default. To activate it securely follow the steps outlined below.
- Click on START MENU.
- TYPE cmd to enter the DOS.
- Type ipconfig /release
 - Then wait
- On the Graphical Interface
 - Click on NETWORK Network and
 Sharing Center Change adapter setting –
 Right Click Local Area Connection(LAC) –
 Click on Disable then Enable.
- Type ipconfig /renew
 - Then wait again for the new IP ADDRESS.




STEP 5: Configure Local Area Network(LAN) Settings

- The MAC ADDRESS
- On the DHCP Table
- Highlight then COPY and PASTE the MAC ADDRESS
- Click SAVE to save the new LAN settings.

NOTE: For the Documentation write down all the IP ADDRESS you change and especially the new IP ADDRESS.

- Repeat this to:
 - COMPUTER 2
 - ACCESS POINT




Note:

- ✓ Reset the device into Factory Setting by pressing the "Factory reset" button in 5 to 10sec.
 - the indicator is when the lights(LED) are flash all together or "Turn On" the device is ready or reset.
- ✓ Before the resetting ACCESS POINT make sure the ROUTER is disconnected and TURN OFF.


STEP 1: Log into the ACCESS POINT (AP) from your computer

- You will need to have a working network card or port with a computer attached in order to connect to the ACCESS POINT. These instructions assume the default AP setup. This guide assumes that you have set up all the physical connections as per the welcome note, found inside the router's box or at the back of device.
- Open a browser (Internet Explorer, Mozilla Firefox, Google Chrome etc.) and type the brand of the router e.g. http://tplinkmodem or type http://192.168.0.254 in the address bar



Step 2:


- Click on Mode Button
- On switch mode, click on Access Point button.
- Click SAVE to save and to continue then wait for reboot.






Step 3:


- Click on Settings
- next click on wireless settings
- Enter a new device name then add a
- "_AP" at the end of choosen name to easy determine.
- Go to dropdown arrow then choose "WPA/WPA2"
- Choose simple Password
- Save





STEP 5: Configure Local Area Network(LAN) Settings

- The LAN is deactivated by default. To activate it securely follow the steps outlined below.
- Click on START MENU.
- TYPE cmd to enter the DOS.
- Type ipconfig /release
 - Then wait
- On the Graphical Interface
 - Click on NETWORK Network and
 Sharing Center Change adapter setting –
 Right Click Local Area Connection(LAC) –
 Click on Disable then Enable.
- Type ipconfig /renew
 - Then wait again for the new IP ADDRESS.




THEN CONNECT all cable (*Cross-Over Cable*) into access point and router to the Switch Hub, then access them synchronized on the browser and at the DOS, type *ping* (then enter *the IP Address* of <u>Router</u> and <u>Access Point</u>) must connected to each other. LASTLY Access them both to the browser.

```
Command Prompt
      ipconfig /renew
      ipconfig /renew EL*
    > ipconfig /release *Con*
   > ipconfig /allcompartments
   > ipconfig /allcompartments /all ... Show detailed information about all
C:\Users\gka>PING 192.168.20.1
 inging 192.168.20.1 with 32 bytes of data:
     from 192.168.20.1: bytes=32 time<1ms TTL=2
 eply from 192.168.20.1: bytes=32 time<1ms TTL=2
 ing statistics for 192.168.20.1:
    Packets: Sent = 4, Received = 4, Lost = 0 (0x loss).
```

On the *Graphical Interface*

Click on NETWORK – Network and
Sharing Center – Change adapter setting
– Right Click - Local Area
Connection(LAC) – Click on Disable then
Enable.



Connect the LAPTOP on the ACCESS POINT



NOTE: Check all MAC Address, must in **STATIC** mode.

At the CENTRAL DEVICE or SERVER


Go to Command Prompt

- Type CMD
- Type getmac

 Look for the MAC ADDRESS of all device and follow the procedure below.
- The MAC ADDRESS
- On the DHCP Table
- Highlight then COPY and PASTE the MAC ADDRESS
- Click SAVE to save the new LAN settings.

NOTE: For the Documentation write down all the IP ADDRESS you change and especially the new IP ADDRESS.


- Repeat this to:
 - COMPUTER (SERVER, CLIENT_PC and CLIENT_LAPTOP)
 - ACCESS POINT




- See all in one Network:
 - Look for the "UNIQUE" IP ADDRESS (192.168.)
 - Look for Default Gateway "SAME"
 - Look for Computer Name "UNIQUE"
 - Look for Workgroup Name "SAME"
- See all Firewall:
 - Set all firewall into "OFF MODE"
- See all Sharing Option:


Steps:

- ✓ Network Network and Sharing Center
 Advance Sharing Settings Network
 Discovery
- ☐ Network Discovery Turn ON
- ☐ File Sharing Turn ON
- ☐ For the Password Turn OFF



- To view all and check if all are connected:
 - ✓ CMD Type **net view** look for the three device.
 - ✓ Graphical look for the three device.





File Sharing (Peer – to – peer)


Note:

SERVER = can share/send

can delete

CLIENT = read/view only

Folder – Properties – Sharing – Share (Advance Setting – Permission)



File Sharing (Peer – to – peer)

Note:

SERVER = can share/send

=

can delete

CLIENT = read/view only

Folder – Properties – Sharing – Share (Advance Setting – Permission)

